



dba **Simple Safety**

@ Finger Shield Safety Product LLC

Website: www.itsSimpleSafety.com

Email: itsSimpleSafety@yahoo.com

904-861-4644 / 561-223-9697

Cell: 330-524-8102

Fax: 561-828-7718



Push Side Installation Instructions


Note: Door gets wedged open for the push side install, see step 3

Push side is interior side of door where you push the door away from you.

- Check over your door, frames and hinges making sure all are **100% defect free, securely fastened and hinge pins are in place.** Make a habit of doing this at least annually.
- Clean your door with an **alcohol based cleaner/degreaser** that your door can handle without damaging it. Allow door to dry prior to product install.
- Pre-drill holes are needed for metal doors and/or kick plates. Use the proper size drill bit; **generally, it will be a 9/64", aka No. 28 HSS Wire gauge drill bit** to make a pilot hole, but that may change according to the screws you are using.
- To **shorten** a guard for doors shorter than standard doors cut at the required length with a pair of strong scissors or Box cutter by heavily scoring and snapping off. If a **longer length** is needed, install an additional piece by butting it at the top end of the guard to continue on up. In conclusion, cut another guard into the size section(s) needed to cover the door length in its entirety.
- The short door guard picture is for illustration purposes only, visualize full length. The actual Safety Door Guard should always be installed as close to the bottom and as high on top of the door and door-frame to as the full length allows; approx. **1/2" clearance at top and bottom**, just enough to secure full safety but not rub. **NOTE:** You should always be covering the entire door because partial door coverage will not allow for the full life span of the product. It allows for too much play, thus causing additional wear and tear, and voids warranty.
- Standard push and pull, along with special door type installation instructions can also be found on our website www.itsSimpleSafety.com

NOTE: Standard doors open to 90 degrees, for openings greater than 90 degrees you must use our push-side WIDE guard. The pull side is always standard, no WIDE needed.

Glass Doors, if unable to use the screws when attaching the hinge to the door side, (frame side should Always be screwed in, one side may be glass thus failing to allow screw in) we recommend you add an additional row(s) of industrial strength two-way adhesive tape to replace the screw area.




Push-Side Installation Instructions


Needed: Safety Guards, Screw driver or drill, screws, pencil or pen, templates

(per emailed instructions and supplies photo)

1. With the door fully closed, use a pencil/pen to draw a guideline from top to bottom on the door frame using a $\frac{3}{4}$ " by 2" $\frac{13}{16}$ measuring block.




2. Repeat the procedure on the door to produce a second guideline.




3. Wedge the door fully open.



- 4a. Remove the protective coating from the tape located at each side of the door guard (**NOTE**: only remove the protective tape strip from one side of the guard at a time and install per step 4b)



- 4b. Line up the edge of the door guard parallel to the guideline on the door frame and press firmly from the center of the door outwards to hold in position. Secure with the screws provided working from the center outwards. Repeat the procedure to attach the door guard to the door.



5. After installing our Preventive & Protective Safety Door Guards, test that the door opens and closes and is fully functional. Clean the door guard with a clean damp cloth; Do Not use solvent.

Reminder & WARNING: Are you checking your door, frames & hinges on a regular basis, at least annually in order to be sure your door has no defects, and/or safety issues? Hinges come loose overtime, thus bringing on other potential defects to the Safety Guard, door, etc.



dba **Simple Safety**

@ Finger Shield Safety Product LLC
Website: www.itsSimpleSafety.com
Email: itsSimpleSafety@yahoo.com
904-861-4644 / 561-223-9697
Cell: 330-524-8102
Fax: 561-828-7718



Pattern For:

Push Measure Blocks / Spacers

Make then out of a sturdy piece of cardboard

Push Side Measurements: $3/4''$ by $2'' 13/16$

Made to measure templates; (verify per above measurements, printing > some printers can create size changes/ issues)

